


seem 4TM mud-in drywall

FSM4-XF



! LUMINAIRE MUST BE INSTALLED PRIOR TO DRYWALL. !
! CONFIGURATIONS ARE RUN SPECIFIC, PLEASE CONSULT FACTORY DRAWINGS BEFORE BEGINNING INSTALLATION. !



FOCAL POINT




PARTS LISTS

SHIPPED IN HARDWARE BAG			
	REFLECTOR (70008) (6-32 X 5/16 PAN-HEAD MACHINE SCREW)		MUD FLANGE (70005) (8-32 X 5/16" FLAT UNDERCUT HEAD SCREW)
	LENS TOOL (A09052-01) (AFFIXED TO LENS, ONE PER RUN)		BACKER FLANGE (72001) (8-32X 3/8" WASHER HEX HEAD SCREW)
			HOUSING SPACER
SHIPPED INSTALLED			
	TIE-WIRE BRACKET SCREW (72010) (8-18 x 1/4 SELF TAPPING SCREW)		JOINER BRACKET (11920)
	TIE WIRE BRACKET (12547)		JOINER BRACKET (11849)
	LENS END PIECE (A07670)		



KEY



BACKER FLANGE PLACEMENT GUIDE





DRYWALL THICKNESS	ORIENTATION	GUIDE POINT	POSITION
3/8"	1	X	F
1/2"	1	X	E
5/8"	1	X	D
3/4"	1	X	C
7/8"	1	X	B
1"	1	X	A
1 1/8"	1	Y	G
1 1/4"	2	Y	F
1 3/8"	2	Y	E
1 1/2"	2	Y	D
1 5/8"	2	Y	C
1 3/4"	2	Y	B
1 7/8"	2	Y	A
2"	2	X	E
2 1/8"	2	X	D







Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
 To prevent electrical shock, disconnect electrical supply before installation or servicing.

CEILING INSTALLATION (SEE PAGE 4 FOR WALL INSTALLATION)






3 USING THE BACKER FLANGE PLACEMENT GUIDE FROM **PAGE 1** DETERMINE THE PROPER PLACEMENT OF THE BACKER FLANGE FOR YOUR DRYWALL THICKNESS.



IF BACKER FLANGES WERE PRE-INSTALLED SKIP TO STEP 5











INDIVIDUAL INSTALLATIONS SKIP TO STEP 11






Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.









MAKE ELECTRICAL CONNECTIONS












Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.








WALL INSTALLATION







Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.



Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.



BALLAST SERVICE



Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.