

# Facetta

FCT



CONNECTED<sup>TM</sup>  
SOLUTIONS

PL Preferred Light  
Experience BETTER COLOR

FOCAL POINT<sup>®</sup>

**⚠ AVOID ALL CONTACT WITH LED SURFACE, LEDs ARE EASILY DAMAGED!**

FOCAL POINT



AIR RETURN

KEY



POWER OFF








POWER ON




ATTENTION

## GRID




MAKE ELECTRICAL CONNECTIONS


## DRYWALL INSTALLATION



SEE FOCAL POINT FRAME KIT  
INSTRUCTION SHEET IS160








MAKE ELECTRICAL CONNECTIONS






Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).  
To prevent electrical shock, disconnect electrical supply before installation or servicing.




## DRIVER SERVICE






## AIR RETURN INSTALLATION








## ENLIGHTED



Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).  
To prevent electrical shock, disconnect electrical supply before installation or servicing.



### ACUITY nLIGHT



### WATTSTOPPER

