

# Seem® 2 LED Perimeter

FSM2PR-XFF | MUD-IN DRYWALL



FOCAL POINT®



## BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

## INSTRUCTION KEY



ATTENTION



SEE ADDITIONAL INSTRUCTIONS




POWER OFF




POWER ON

## COMPONENT KEY


### FOCAL POINT




Corner




U - Individual




S - Start of Run



I - Intermediate




E- End of Run




Adjustable Housing

J-Rail  
(Adjustable housing)



Z-Rail  
(Adjustable housing)



Corner J-Rail  
(Adjustable housing)

### PARTS SHIPPED INSTALLED




Reflector Screw  
(72026)  
(6-20 x 1/4 self tapping screw)




Tie-Wire Bracket Screw  
(72010)  
(8-18 x 1/4 self tapping screw)




Joiner Screw  
(72118)



Tie-Wire Bracket  
(12547)



Joiner Bracket  
(A63039-01)




Joiner Blocker  
(A48495-01-WH)









FOCAL POINT RECOMMENDS  
STARTING WITH CORNER  
INSTALLATION IF APPLICABLE







**BASIC INSTALLATION, STEPS 1-16**  
**ADJUSTABLE HOUSING, PAGE 4**  
**CORNERS, PAGE 5**

## WALL/CEILING PREPARATION










## BASIC INSTALLATION





**REPEAT STEPS 2 - 11 FOR EACH HOUSING SECTION**





## EMERGENCY

**I**

SEE BATTERY MANUFACTURER  
INSTRUCTIONS

EMERGENCY MAXIMUM MOUNTING HEIGHT  
FROM FLOOR TO SURFACE OF LENS:

**17.9'**

## ADJUSTABLE HOUSING

**1**

**I**

FOLLOW BASIC INSTALLATION  
INSTRUCTIONS 1-12 ON PAGES 2-3

**2**

LOOSEN  
SCREWS  
(DO NOT REMOVE)

**3**

ADJUST HOUSING TO  
DETERMINED LENGTH

**4**

TIGHTEN  
SCREWS

**5**










CUT LENS TO DETERMINED LENGTH

**6**

**7**

MAKE ELECTRICAL CONNECTION

## CORNERS



## DRIVER SERVICE

