


# seem™ 4 surface mount

FSM4S-SM



**! CONFIGURATIONS ARE RUN SPECIFIC, PLEASE CONSULT FACTORY DRAWINGS BEFORE BEGINNING INSTALLATION. !**

## FOCAL POINT



## KEY



POWER OFF



POWER ON



ATTENTION



SEE ADDITIONAL INSTRUCTIONS



INDIVIDUAL  
INSTALLATIONS FOLLOW  
STEPS 1-3 & 7-11



## MOUNTING





FEED LOCATION IS ALWAYS CENTERED IN HOUSING.  
USE SINGLE DEVICE COVER OR SINGLE GANG HANDY BOX  
AND MOUNTING HARDWARE (BY OTHERS)

## PARTS LISTS












### SHIPPED IN HARDWARE BAG




### SHIPPED INSTALLED



Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).  
To prevent electrical shock, disconnect electrical supply before installation or servicing.



Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).  
To prevent electrical shock, disconnect electrical supply before installation or servicing.



## BALLAST SERVICE

