


FOCAL POINT



WIRING COMPARTMENT SHIPS WITH 2' HOUSING ONLY.

KEY



POWER OFF



POWER ON




ATTENTION




8" CLEARANCE ABOVE COVE RECOMMENDED FOR ALL APPLICATIONS


horizontal base with adjustable light scoop also available without light scoop



vertical base




1




OPTIONAL - SECURE HOUSING TO COVE

2

HORIZONTAL BASE




VERTICAL BASE




2' HOUSING ONLY


3



4






5




Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.







Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.




2' HOUSING ONLY





BEAM AIMING





Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.



DRIVER SERVICE - HORIZONTAL BASE



DRIVER SERVICE - VERTICAL BASE



Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
 To prevent electrical shock, disconnect electrical supply before installation or servicing.