Seem® 1 Point Source

Grid Ceiling | FSM1D





BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

INSTRUCTION KEY



ATTENTION



SEE ADDITIONAL INSTRUCTIONS




POWER OFF




POWER ON


PRODUCT ID LOCATION




COMPONENT KEY

FOCAL POINT Individual Start of Run







SHIPPED INSTALLED




Joiner Screw (72074)



Joiner Washer (700158)



Linear Joiner **Bracket** (A37621-01)





INSTALLED IN SOME, BUT NOT ALL INSTANCES. COMPLETE INSTALL OF RUN PRIOR TO TRIM ASSEMBLY INSTALLATION.


SHIPPED IN HARDWARE BAG




Reflector Screw (72026)(#6x1/4 Self Tapping Screw)




LAY-IN GRID SPACING




TEGULAR GRID SPACING





RAIL & CLIP GUIDE





▲ INDIVIDUAL INSALLATIONS FOLLOW STEPS 1, 2 & 6



















DRIVER SERVICE - INTEGRATED POINT SOURCE





DRIVER SERVICE - POINT SOURCE ONLY

