

Seem® 1 Point Source

Mud-In Drywal | FSM1D-XF

PL Preferred Light
Experience BETTER COLOR



BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

INSTRUCTION KEY



ATTENTION



SEE ADDITIONAL INSTRUCTIONS




POWER OFF




POWER ON

PRODUCT ID LOCATION




COMPONENT KEY


FOCAL POINT




U - Individual




S - Start of Run




I - Intermediate




E - End of Run



Flush Lens



Point Source Only Faceplate




Mud Flange


SHIPPED INSTALLED



Tie-Wire Bracket Screw (72010)
(8-18 x 1/4 Self Tapping Screw)



Tie Wire Bracket
(A38635-01)



Point Source Trim Assembly




POINT SOURCE TRIM ASSEMBLY SHIPS INSTALLED IN SOME, BUT NOT ALL INSTANCES.

SHIPPED IN HARDWARE BAG




Reflector Screw
(72026)
(8-18 x 1/4 Self Tapping Screw)

1




2"X6" FRAMING REQUIRED ON BOTH SIDES OF HOUSING

2



OPTIONAL


3



OPTIONAL

4

INDIVIDUAL AND
FEED LOCATION ONLY




INTEGRATED POINT SOURCE



AVOID ALL CONTACT WITH LED SURFACE,
LEDs ARE EASILY DAMAGED!


4a

INDIVIDUAL AND
FEED LOCATION ONLY




POINT SOURCE ONLY

5



SECURE TO STRUCTURE ABOVE


6



INDIVIDUAL AND
FEED LOCATION ONLY

INTEGRATED POINT SOURCE


6a



INDIVIDUAL AND
FEED LOCATION ONLY


POINT SOURCE ONLY

7






MAKE ELECTRICAL CONNECTIONS

8









INDIVIDUAL AND
FEED LOCATION ONLY



INTEGRATED POINT SOURCE




**LENS MUST BE INSTALLED PRIOR
TO DRYWALL INSTALLATION**

INDIVIDUAL INSTALLATIONS SKIP TO STEP 12





DRIVER SERVICE - INTEGRATED POINT SOURCE



DRIVER SERVICE - POINT SOURCE ONLY

