

# Seem™ 2 Indirect

Wall Mount | FSM2IW



## BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

## INSTRUCTION KEY



**ATTENTION**



**SEE ADDITIONAL INSTRUCTIONS**




**POWER OFF**




**POWER ON**

## COMPONENT KEY

### FOCAL POINT



### SHIPPED INSTALLED



Joiner Bracket  
(A53548-01)

### SHIPPED IN HARDWARE BAG



Mounting Screw  
(700322)  
(2 per luminaire)



Joiner Screw  
(72118)




Configurations are run specific, please consult factory drawings before beginning installation.

## ! INDIVIDUAL UNIT INSTALLATION FOLLOW STEPS 1-6, 11 & 12




Use 1/2" trade size conduit (by others) for electrical feed. DO NOT USE J-BOX.



**1**














Dimensions shown are from the room side observing the wall.



Feed location is the same for all housing lengths

Luminaire outline



## DRIVER SERVICE

