

# Seem® 4 LED Asymmetric

FSM4ALS | Suspended



## BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

## INSTRUCTION KEY



**ATTENTION**



**SEE ADDITIONAL INSTRUCTIONS**




**POWER OFF**




**POWER ON**


## FOCAL POINT




**U** - Individual Unit



**S** - Start of Run



**I** - Intermediate



**E** - End Of Run



CONFIGURATIONS ARE RUN SPECIFIC, CONSULT FACTORY DRAWINGS BEFORE BEGINNING INSTALLATION.

## PARTS LIST


### SHIPPED IN HARDWARE BAG



Reflector Screw (70008)  
(6-32 X 5/16 Pan-Head Machine Screw)



Cable Gripper  
(73014) &  
Nylon Nut  
(70044)



Lens Tool  
(A09052-02)  
(Affixed To Housing.  
One Per Run)


### SHIPPED INSTALLED




Joiner Pin  
(W5687)



Joiner Bracket  
(18338)



















Lens End Piece  
(A08904)



Joiner Bracket  
(11849)

**! INDIVIDUAL UNITS FOLLOW STEPS 1, 2, 5 & 6**





## EMERGENCY



## DRIVER SERVICE

