Seem 4 LED Perimeter CONNECTED (8)

FSM4PR | GRID/TRIMLESS DRYWALL





FOCAL POINT



BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

INSTRUCTION KEY



ATTENTION



SEE ADDITIONAL INSTRUCTIONS




POWER OFF



POWER ON

COMPONENT KEY



1 Housing

2 Adjustable housing

3 Sliding sleeve (ss) (shipped installed. SSB indicates a sliding sleeve at both ends)

4 Finish plate

5 J-rail

6 Z-rail

7 Housing rail kit

8 Tie-wire/grid bracket

9 Tie-wire bracket

10 Joiner bracket

11 Joiner bracket

12 Corner j-rail

13 Hardware bag

14 Outside corner

15 Inside corner

BY OTHERS:


Grid ceiling -15/16" or 9/16" flat tee main runner required for finish edge.


HOUSING TYPES - 4' SHOWN

INTERMEDIATE



INDIVIDUAL (MAY INCLUDE SLIDING SLEEVES)







END (SHOWN WITH SLIDING SLEEVE)





ADJUSTABLE HOUSING

WALL/CEILING PREPARATION











WALL/CEILING PREPARATION






OPTIONAL REMOVE END CAP FLANGE ON START AND/OR END OF RUN HOUSINGS WHEN FLUSH **INSTALLATION AGAINST** FINISHED WALL IS DESIRED




FOCAL POINT RECOMMENDS STARTING WITH CORNER INSTALLATION IF APPLICABLE


BASIC INSTALLATION, STEPS 1-13 ADJUSTABLE HOUSING, PAGE 3 SLIDING SLEEVES, PAGE 5 CORNERS, PAGE 6


SLIDING SLEEVE PAIRS (SSB) START & END WITH A SLIDING SLEEVE




BASIC INSTALLATION











START, INTERMEDIATE, & END UNITS ONLY



































EMERGENCY


ADJUSTABLE HOUSING







































SLIDING SLEEVES




MAX LENGTH 12" PER SLEEVE



SLIDING SLEEVE DOES NOT INTEGRATE WITH ADJUSTABLE HOUSING

SINGLE SLIDING SLEEVE (SS):


EXAMPLE:





SLIDING SLEEVE PAIR (SSB):


EXAMPLE:


21' RUN LENGTH - 20' HOUSING = 12" SLIDING SLEEVE (21' RUN LENGTH - 20' HOUSING) / 2 = 6" SLIDING SLEEVE ON EACH END




























CORNERS





















DRIVER SERVICE






START, INTERMEDIATE, & END UNITS ONLY


START, INTERMEDIATE, & END UNITS ONLY





GRID ONLY


WATTSTOPPER






























ENLIGHTED



















WAVELINX




















WAVELINX








ACUITY nLIGHT












WATTSTOPPER



HUBBELL NX

