ID+ 2.5" Square Adjustable

FLCS22-SO





BEFORE YOU BEGIN

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

INSTRUCTION KEY



ATTENTION



SEE ADDITIONAL INSTRUCTIONS



POWER OFF




POWER ON



COMPONENT KEY

HOUSING







TRIM




Solite Lens

Spot Optic, no lens 0°-15° tilt

Spot Optic, no lens


15°-35° tilt


OPTIONAL BAR HANGERS SOLD SEPARATELY




Emergency - Remote Test Switch










GRID - 1/2" CONDUIT & CLIP (BY OTHERS)










GRID - BAR HANGERS (SOLD SEPARATELY)











Multiple Luminaires Only


DRYWALL - BAR HANGERS (SOLD SEPARATELY)






















A ABOVE CEILING ACCESS REQUIRED




















EM - MOUNTING HEIGHT




SEE

BATTERY MANUFACTURER INSTRUCTIONS


Emergency maximum mounting height: Clear Diffuse & White - 17.71' Warm Diffuse & Black - 17.15'

ROTATE




USE ADJUSTMENT HANDLE TO ROTATE UP TO 362°


TILT




USE ADJUSTMENT HANDLE TO TILT UP TO 35°



TRIM INSTALLATION





OPTIC SERVICE





DISTRIBUTION KITS INCLUDE AN OPTIC AND REFLECTOR ASSEMBLY.


BOTH ITEMS MUST BE USED


TO ACHIEVE SPECIFIED

DISTRIBUTION.









DRIVER SERVICE



TO PREVENT ELECTRICAL SHOCK, **DISCONNECT ELECTRICAL SUPPLY BEFORE SERVICING**

