# seem 4<sup>™</sup> LED mud-in drywall





POWER OFF

POWER ON


**KEY** 





PARTS LISTS


CONFIGURATIONS ARE RUN SPECIFIC, PLEASE CONSULT FACTORY DRAWINGS BEFORE BEGINNING INSTALLATION.

















MUD FLANGE (SHIPPED LOOSE)





DRYWALL THICKNESS	ORIENTATION	GUIDE POINT	POSITION
3/8"	1	Х	F
1/2"	1	Х	E
5/8"	1	Х	D
3/4"	1	Х	С
7/8"	1	Х	В
1"	1	Х	Α
11/8"	1	Υ	G
11/4"	2	Υ	F
13/8"	2	Υ	E
11/2"	2	Υ	D
15/8"	2	Υ	С
13/4"	2	Υ	В
17/8"	2	Υ	А
2"	2	Х	E
21/8"	2	Х	D



## CEILING INSTALLATION (SEE PAGE 4 FOR WALL INSTALLATION)










USING THE BACKER FLANGE
PLACEMENT GUIDE FROM
PAGE 1 DETERMINE THE
PROPER PLACEMENT OF THE
BACKER FLANGE FOR YOUR
DRYWALL THICKNESS.


IF BACKER FLANGES WERE PRE-INSTALLED SKIP TO STEP 5



























MAKE ELECTRICAL CONNECTIONS

DRYWALL












Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).


To prevent electrical shock, disconnect electrical supply before installation or servicing.





### POP-DOWN LENS






#### WALL INSTALLATION

1




2"x6" FRAMING REQUIRED ON BOTH SIDES OF OF HOUSING





USING THE BACKER FLANGE
PLACEMENT GUIDE FROM
PAGE 1 DETERMINE THE
PROPER PLACEMENT OF THE
BACKER FLANGE FOR YOUR
DRYWALL THICKNESS.


IF BACKER FLANGES WERE PRE-INSTALLED SKIP TO STEP 4













































### FLUSH LENS





### POP-DOWN LENS






### DRIVER SERVICE







### **EMERGENCY**



SEE BATTERY MANUFACTURER INSTRUCTIONS

EMERGENCY MAXIMUM MOUNTING HEIGHT: 13.00'

Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.