# Seem 4 LED Perimeter CONSECTED (4)

FSM4PR | GRID/TRIMLESS DRYWALL









### **BEFORE YOU BEGIN**

- Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
- To prevent electrical shock, disconnect electrical supply before installation or servicing.
- Contractor is responsible for adequately reinforcing walls and/or ceilings to support fixture weight.
- Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings.
- The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.

#### **INSTRUCTION KEY**



**ATTENTION** 



**SEE ADDITIONAL INSTRUCTIONS** 




**POWER OFF** 



POWER ON

#### **COMPONENT KEY**



1 Housing

2 Adjustable housing

3 Sliding sleeve (ss) (shipped installed. SSB indicates a sliding sleeve at both ends)

4 Finish plate

5 J-rail

6 Z-rail

7 Housing rail kit

8 Tie-wire/grid bracket

9 Tie-wire bracket

10 Joiner bracket

11 Joiner bracket

12 Corner j-rail

13 Hardware bag

14 Outside corner

15 Inside corner

#### BY OTHERS:

Grid ceiling -15/16" or 9/16" flat tee main runner required for finish edge.

#### **HOUSING TYPES - 4' SHOWN**



INDIVIDUAL (MAY INCLUDE SLIDING SLEEVES)







INTERMEDIATE








END (SHOWN WITH SLIDING SLEEVE)


ADJUSTABLE HOUSING

# **WALL/CEILING PREPARATION**












### **WALL/CEILING PREPARATION**










FOCAL POINT RECOMMENDS STARTING WITH CORNER INSTALLATION IF APPLICABLE

BASIC INSTALLATION, STEPS 1-13 ADJUSTABLE HOUSING, PAGE 3 SLIDING SLEEVES, PAGE 5 CORNERS, PAGE 6


SLIDING SLEEVE PAIRS (SSB) START & END WITH A SLIDING SLEEVE





#### **BASIC INSTALLATION**













































# **ADJUSTABLE HOUSING**





































# **SLIDING SLEEVES**




MAX LENGTH 12" PER SLEEVE



SLIDING SLEEVE DOES NOT INTEGRATE WITH ADJUSTABLE HOUSING


#### SINGLE SLIDING SLEEVE (SS):


## EXAMPLE:





#### **SLIDING SLEEVE PAIR (SSB):**


EXAMPLE: 21' RUN LENGTH - 20' HOUSING = 12" SLIDING SLEEVE (21' RUN LENGTH - 20' HOUSING) / 2 = 6" SLIDING SLEEVE ON EACH END




























# **CORNERS**






















# **DRIVER SERVICE**






START, INTERMEDIATE, & END UNITS ONLY


START, INTERMEDIATE, & END UNITS ONLY




















# CONNECT CAT-5 CABLE